






5
Stop the machine in this position.





6
Connect your side chain loosely.





10A
If you can, couple the chain together ring to ring with either a shackle or plug coupler provided.



10B
If you can't connect ring to ring, pull your tail chain through the ring & connect to the side chain.



7
Hook up your tag chains to the side chain with shackles or plug couplers provided.




11 Tighten your side chain. Use the tensioning device (not included) to tighten. You will be able to remove a lot of slop in the bottom of the chain just by tightening one link per side.




12 Last step is to cut your side chain or tie it back so it doesn't flail. Also, if you connected your main pattern ring to ring, cut the tails completely off.
(Remove installation chain/rope)



8
Hook the tag chains in a manner that follows the fixed side chain.



9
Use a tensioning device (not included) to bring the rings close together. This will tighten up the main pattern.



13 Move the skidder forward and backward numerous times to ensure the chain is fully seated. Refer back to Steps 10 -12 if the chains need further tightening.

PRODUCTS SUPPLIED

SHACKLES

PLUG COUPLERS

OPTIONAL PARTS & TOOLS REQUIRED FOR INSTALLATION IF AVAILABLE

MOUNTING TOOL

PRY BAR

IMPACT WRENCH

QUESTIONS?

CONTACT US:
OCCANADA

1-888-507-9734
info@qccanada.com
www.qccanada.com